

# **EQ** Series

OEM Aluminum NFPA Interchangeable Cylinder Line



# numatics



# **Table of Contents**



3-	3
· · · · · · · · · · · · · · · · · · ·	
	4
eries Piston Rod Assembly	5
eries Repair Kit	6
eries Seal Kit	6
Kit Installation Instructions	
it Removal/Installation Instructions	7
	8
e	9
10-	1
	3

2





The **EQ Series** combines cost-effectiveness with proven dependability. It is a repairable OEM NFPA Interchangeable cylinder line that was specially designed to give our customers an economical alternative. This Non-Lube air cylinder offers elasticity to tight design budgets without sacrificing quality.

#### **Tube**

The **tube** is hard coat anodized. The hard coating is an electrochemical process, which produces a very dense surface of aluminum oxide. This surface has extreme hardness (60 RC.), excellent wear and corrosion resistance, and low coefficient of friction.

#### **End Caps**

The **end caps** are accurately machined from (6061-T6) solid aluminum bar stock. They are anodized for corrosion resistance. Additionally, a recess on the pistonmating surface (at both ends) enables the air to work on a larger piston area for effortless breakaway.

#### **Rod Bushing**

The A Series includes a graphite filled, cast iron rod bushing that is extra long in length. Graphite filled offers the best bearing surface when using a hard chrome plated piston rod. Cast iron provides maximum resistance against wear. The added length adds superior alignment and support of the piston rod as well as provides maximum load bearing support.

#### Rod Seal

The nitrile, rounded lip design ensures proper sealing and long life.

#### Rod Wipe

The standard **rod wiper** construction is a highly durable polyurethane.

#### **Piston Rod**

High strength steel (100,00 psi minimum yield) **piston rod** has a ground, polished, and chrome plated surface. This surface provides maximum life for both the rod bushing and the seals.

#### **Bushing Retainer**

The **bushing retainer** allows cartridge removal (cylinder repair) without complete disassembly.

#### Tie-Rods

The **tie rods** are 100,000 psi minimum yield steel for maximum holding power. They are roll formed for superior strength and engagement.

#### Piston Seal

The piston seal is a nitrile over-sized o-ring seal.

#### Wear Band

The **wear band** is a stable, lubricating strip located on the piston. We separated the load bearing points by locating the wear band at the rear of the piston. This maximizes column strength at full extension.

Reference the A Series section for drawings and dimensional information.



The solid aluminum alloy **piston** is strong and durable.

#### **Cushion Seal**

The floating **cushion seal** design enables rapid stroke reversal by providing instantaneous full flow to the piston. Each cushion has a flush, retained adjustment needle.

#### **Tube End Seal**

The tube end seals are compression type and reusable.

#### Ports

Our enhanced **port** design enables the cylinder to work more efficiently. Through the use of precise machining depths and tool shape, we are able to smooth the flow path into and out of the cylinder.


#### **Standard Specifications:**

- Meets NFPA specifications
- Bore sizes from 1-1/2" through 6"
- Piston rod diameters from 5/8" to 1-3/4"
- Nominal pressure rating is 250 psi air
- Standard temperature -10°F to 165°F (-23°C to 74°C)
- NPTF ports
- · Multitude of mounting options





# How to Order - EQ Series Cylinder




Reference the A Series section for drawings and dimensional information.





## How to Order - EQ Series Piston Rod Assembly



**Note:** Options listed are ones that apply to a piston rod assembly only. Model number is set up to use option code supplied with original cylinder or with any above.

#### Rod Fnd Styles, Diameters and Threads

TIOG ETIG	Otyloo, Diamot	oro arra irrioan	<u> </u>
Diameter	Style #1 Standard Male	Style #2 Optional Male	Style #3 Optional Female
0.625	7/16-20	1/2-20	7/16-20
1.000	3/4-16	7/8-14	3/4-16
1.375	1-14	1 1/4-12	1-14
1 750	1 1//-19	1 1/2-12	1 1//-12


#### Rod Diameters by Bore Size

Bore	Standard Dia.	Oversized Dia.
1-1/2"	0.625	1.000
2"	0.625	1.000
2-1/2"	0.625	1.000
3-1/4"	1.000	1.375
4"	1.000	1.375
5"	1.000	1.375
6"	1 375	1 750






## How to Order - EQ Series Repair Kit



Note: Options listed are ones that apply to a repair kit only.

Model number is set up to use option code supplied with original cylinder or with any above.

#### How to Order - EQ Series Seal Kit



Note: Options listed are ones that apply to a seal kit only.

Model number is set up to use option code supplied with original cylinder or with any above.





### Piston Rod Assembly Kit Removal/Installation Instructions

- 1. Loosen 4 Tie Rod Nuts (Part #18) to remove Piston/Rod Assembly (Part #15 & #16).
- 2. Carefully remove old seals and wearband. (Part #12 & #14). Any damage to the seals may result in leakage.
- 3. Lubricate piston seal(s) and wearband (Part #12) with supplied Numatics' Lube. Examine seals before installing for any contamination. Contamination may cause leakage.
- 4. Install Piston Seal (Part #14). Make sure the piston seal is not twisted inside groove.
- 5. Install lubricated wearband onto piston. Sink piston/rod assembly into sinker tube. See Sinker Tube Part Numbers Chart.
- 6. Apply lube inside the cylinder tube.
- 7. Sink piston/rod assembly into cylinder tube.
- 8. Press piston/rod assembly flush with the cylinder tube. Wipe off any lube from the face of the piston.
- 9. Examine all seals before reassembling cylinder for any contamination. Contamination may cause leakage.
- 10. Lightly grease Rod Seal (Part #3) of Loaded Bushing before installing. This will ease the installation of the rod bushing over the rod.
- 11. Reassemble cylinder. Loosely torque tie rod nuts to allow head and cap to rotate slightly.
- 12. Before final torque, place cylinder on level surface. This will ensure that the cylinder head and cap are square. Torque tie rod nuts in a crisscross pattern. Use torque tolerance charts for tie rod nuts.
- 13. Stroke cylinder by hand. This will enable detection of any binding. If binding does occur, repeat steps 11 -13.

See Seal Installation Guide on page 9 for additional (visual) instructions.

### Repair Kit and Seal Kit Removal/Installation Instructions

- 1. Loosen 2 or 4 Retainer Screws (Part #11) to remove Bushing Retainer (Part #10) and Loaded Bushing (Part #9).
- 2. Loosen 4 Tie Rod Nuts (Part #18) to remove Head (Part #8) and Piston/Rod Assembly (Part #15 & #16).
- 3. Carefully remove old seals and wearband. (Part [#1, #2, #3 Seal Kit only], #5, #6, #7, #12, & #14) Any damage to the seal grooves may result in leakage.
- Lubricate new seals with supplied Numatics' Lube. Examine seals before installing for any contamination. Contamination may cause leakage.
- 5. Install Piston Seal (Part #14). Make sure the piston seal is not twisted inside groove.
- 6. Install lubricated Wearband (Part #12) onto piston. Sink piston/rod assembly into sinker tube. See Sinker Tube Part Numbers Chart.
- 7. Apply lube inside the cylinder tube.
- 8. Sink piston/rod assembly into cylinder tube.
- 9. Press piston/rod assembly flush with the cylinder tube. Wipe off any lube from the face of the piston.
- 10. Place Tube End Seals (Part #6) into head and cap seal grooves. Examine seals after installing for any contamination. Contamination may cause leakage.
- 11. Install Rod Wiper (Part #1), Bushing O-ring (Part #2), and Rod Seal (Part #3) into bushing (Seal Kit only). Lightly grease Rod Seal and Bushing O-ring after installation. This will ease the installation of the rod bushing over the rod and into the
- 12. Reassemble cylinder except for loaded rod bushing. First, loosely torque tie rod nuts to allow head and cap to rotate slightly. Carefully place bushing over the rod until getting interference. With a twisting motion, slide the bushing down onto the rod and into the bushing pocket on the head.
- 13. Place Bushing Retainer (Part #10). Lightly tighten retainer screws.
- 14. Before final torque, place cylinder on level surface to square head and cap. Torque tie rod nuts in a crisscross pattern. Use the torque tolerance chart for Tie Rod Nuts and Retainer Screws.
- 15. Stroke cylinder by hand. This will enable detection of any binding. If binding does occur, repeat steps 12-14.

See Seal Installation Guide on page 9 for additional (visual) instructions.









# Diagrams


Pneumatic Service Temperatures: Nitrile Seals: -10°F (-23°C) to 165°F (74°C) Viton® Seals: 0°F (-17°C) to 400°F (204°C)



Head, Cap, and Bushing Assembly



Piston/Rod Assembly



Cylinder Assembly and Tie Rod Torque


#### **EQ** Series


	EQ OC	Parts included in:				
Part #	Description	Seal Kit	Repair Kit	Piston/Rod Assembly		
1	Rod Wiper	Χ				
2	Bushing O-ring	Χ				
3	Rod Seal	X				
4	Cap					
5	Cap Cushion Seal	Х	Х			
6	Tube End Seals	Χ	Х			
7	Head Cushion Seal	Χ	Х			
8	Head					
9	Loaded Bushing Assembly		Х			
10	Bushing Retainer					
11	Retainer Screws					
12	Wearband	Χ	Х			
13	Magnet			Χ		
14	Piston Seal	Χ	Х			
15	Rod			Χ		
16	Piston			Х		
17	Tube					
18	Hex Nuts					
19	Tie Rods					
20	Head Cushion Spear			Х		






## Seal Installation Guide







Loaded Bushing

Cushioned Head or Cap

O' Ring Piston

## Torque Tolerances (lbs-ft) Tie Rod Nut Part #19

Bore	Min.	Max.
1-1/2"	8	10
2"	15	20
2-1/2"	15	20
3-1/4"	23	30
4"	23	30
5"	50	60
6"	50	60

Retainer Screws Torque Tolerances (lbs-ft) Part #11

Size	Min.	Max.
#10-32	1	1.5
1/4-28	5	7
5/16-24	10	12

Note: Sinker Tubes are not included in kits. They can be ordered using the part numbers from the provided chart.

### Sinker Tube Part Numbers

Bore	Min.
1-1/2"	A06-K91
2"	A06-L91
2-1/2"	A06-M91
3-1/4"	A06-P91
4"	A06-R91
5"	A06-T91
6"	A06-U91








## **EQ Series Switch Information**

# EQ Series World Switch Application Detail

#### Round Tube and Tie Rod Detail

- 1. World Switch
- 2. Tie Rod Bracket
- 3. Adjustment Screw
- 4. Cylinder Tie Rod




## **EQ Series World Switch Bracket**

Cylinders	Bore	Part Number
EQ series Tie Rod	1 1/2"	SB6-K01
EQ series Tie Rod	2"-2 1/2"	SB6-L01
EQ series Tie Rod	3 1/4"-4"	SB6-P01
EQ series Tie Rod	5"-6"	SB6-T01

## EQ series World Switch Hall Effect Part Numbers

P/N	Switch Style	Switch Type	Function	Switching Voltage	Switching Current	Switching Power	Voltage Drop
SH6-031	3m Wire Version	Hall Effect for Reed Magnet & Light Sourcing	Normally Open Sourcing (PNP)	6 -24 VDC	0.3 Amps Max.	7.2 Watts Max.	0.5 Volts
SH6-021	8m Connector Pigtail	Hall Effect for Reed Magnet & Light Sourcing	Normally Open Sourcing (PNP)	6 -24 VDC	0.3 Amps Max.	7.2 Watts Max.	0.5 Volts
SH6-032	3m Wire Version	Hall Effect for Reed Magnet & Light Sourcing	Normally Open Sourcing (NPN)	6 -24 VDC	0.3 Amps Max.	7.2 Watts Max.	0.5 Volts
SH6-022	8m Connector Pigtail	Hall Effect for Reed Magnet & Light Sourcing	Normally Open Sourcing (NPN)	6 -24 VDC	0.3 Amps Max.	7.2 Watts Max.	0.5 Volts

#### Hall Effect Switch











## EQ Series World Switch Reed Switch Part Numbers

P/N	Switch Style	Switch Type	Function	Switching Voltage	Switching Current	Switching Power	Voltage Drop
SR6-002	3m Wire Version	Reed Switch, LED	SPST Normally Open	5 -120V AC/DC	0.025 Amps Max. 0.001 Amps Min.	3 Watts Max.	3.5 Volts
SR6-004	3m Wire Version	Reed Switch, LED & MOV	SPST Normally Open	5 -120V AC/DC	0.5 Amps Max. 0.005 Amps Min.	10 Watts Max.	3.0 Volts
SR6-021	8mm Pigtail	Reed Switch	SPST Normally Open	0 -120V AC/DC	0.5 Amps Max.	10 Watts Max.	0 Volts
SR6-022	8mm Pigtail	Reed Switch, LED	SPST Normally Open	5 -120V AC/DC	0.025 Amps Max. 0.001 Amps Min.	3 Watts Max.	3.5 Volts
SR6-024	8mm Pigtail	Reed Switch, LED & MOV	SPST Normally Open	5 -120V AC/DC	0.5 Amps Max. 0.005 Amps Min.	10 Watts Max.	3.0 Volts

# Reed Switch - Normally Open Type SR6



# Cords M8-thread for Switches and Sensors with Connector



# Dimensions (mm)

Туре		Α	В	С	D	Е	Weight (approx. kg)	Order Code
Straight with 5m-cable	(3x0.25 mm <sup>2</sup> )	32.3	24.4	_	9.0	_	0.143	SC6-001
Elbow with 5m-cable	(3x0.25 mm <sup>2</sup> )	26.3	17.1	9.2	9.0	8.0	0.145	SC6-002






## **EQ Series Global Application Detail**

#### Round Tube and Tie Rod Detail


- 1. Global Switch
- 2. Tie Rod Bracket
- 3. Adjustment Screw
- 4. Cylinder Tie Rod



#### EQ Series Global Switch Bracket

Cylinders	Bore	Part Number
EQ series Tie Rod	1 1/2"-2 1/2"	N199-1017
EQ series Tie Rod	3 1/4"-4"	N199-1018
EQ series Tie Rod	5"-6"	N199-1019
EQ series Tie Rod	5"-6"	SB6-T01


## Reed Switch (AC/DC NO), flying lead - RSS02, 8mm connector - RSQ02








# Electronic Switch (PNP NO), flying lead - HPNPS31, 8mm connector - HPNPQ31





#### Sensing Data

# -13 to +158 (-25 to +70) (°F/°C)

#### **Electrical Data**

Rated operational voltage U <sub>e</sub>
Supply voltage U <sub>B</sub>
incl. ripple
Voltage drop U <sub>d</sub> at I <sub>e</sub> Stat./dyn.
Rated insulation volatage Ui
Rated supply frequency
Rated operational current le
No-load supply current Io at Ue d./un
Protected against polarity reversal

(1/0)	- 10 to + 100 (-20 to +10)
(% of )	<= 0.3%/°C
(kHz)	10
(ms)	.05
(ms)	.05
	DC13
	YES

(V)	24 DC
(V)	1030 DC
(% of U <sub>e</sub> )	15
(V)	1/–
(V)	75 AC
(Hz)	DC
(mÁ)	200
(mA)	25/13
, ,	YES


#### Mechanical Data


Housing material		Polyamide
Material of sensing face		Polyamide
Connection		PVC cable
Degree of Protection	IΡ	67
Rated shock: half-sinus, 30 g, 11 ms		

Rated vibration environment: 55 Hz, 1mm amplitude, 3 x 30



# Electronic Switch (NPN NO), flying lead - HNPNS32, 8mm connector - HNPNQ32





#### Sensing Data

Electrical Data Rated operational voltage Ue Supply voltage UB incl. ripple

Voltage drop U<sub>d</sub> at I<sub>e</sub> Stat./dyn. Rated insulation volatage U<sub>i</sub> Rated supply frequency

Rated operational current I<sub>e</sub> No-load supply current I<sub>O</sub> at U<sub>e</sub> d./und. Protected against polarity reversal

Ambient temperature range d	(°F/°C)
Temperature drift	(% of S,
Frequency of operating cycles f at U <sub>e</sub>	(kHz)
Turn on time t	(ms)
turn off time t	(ms)
Utilization categories	
Function-/supply voltage indication	

(°F/°C)	-13 to +158 (-25 to +70)
(% of S <sub>r</sub> )	<= 0.3%/°C
(kHz)	10
(ms)	.05
(ms)	.05
	DC13
	YES

% of S <sub>r</sub> )	<= 0.3%/°C
Hz)	10
ns)	.05
ns)	.05
	DC13
	YES
Λ	24 DC

(V)	24 DC
(V)	1030 DC
(% of U <sub>e</sub> )	15
(V)	1/–
(V)	75 AC
(Hz)	DC
(mA)	200
(mA)	25/13
	YES


Mechanical Data		
Housing material		Polyamide
Material of sensing face		Polyamide
Connection		PVC cable
Degree of Protection	IΡ	67
Rated shock: half-sinus, 3	30 g, 11 ms	
Rated vibration environme	ent: 55 Hz. 1	mm amplitude, 3 x 30





# numatics

# World Class Supplier of Pneumatic Components



#### **WORLD HEADQUARTERS**

## USA Numatics, Incorporated

46280 Dylan Drive Novi, Michigan 48377 P: 1-888-Numatics

1-888-686-2842

Canada Numatics, Ltd

P: 519-452-1777

Mexico
Numatics de Mexico S.A. de C.V.

P: 52-222-284-6176

For a comprehensive listing of all Numatics production and distribution facilities worldwide, visit:

www.numatics.com